# CYTRACOM



Cytracom D2

Quick User Guide

# USING THE HEADSET OR SPEAKER

 Use the Speaker Button to turn speaker ON/OFF.
Use the Headset button not to use the headset once it had been connected.

## MAKING A CALL

1) Take Handset/Headset off-hook or press Speaker button or an available LINE key (activates speakerphone).

2) The line will have dial tone and the corresponding lines LED will turn green.

3) Enter the phone number.

4) Press the SEND button or press the "DIAL" soft key.

# REDIAL

1) Take the phone off-hook.

2) Press the SEND button or press the "REDIAL" soft key.

**ANSWERING CALLS** 

# Single Incoming Call:

1) Answer call by taking Handset/Headset off hook or pressing SPEAKER or by pressing the corresponding account LINE button.

## **Multiple Incoming Calls:**

1) When there is a call waiting, users will hear a call waiting tone.

2) The next available line will flash red.3) Answer the incoming call by pressing its corresponding LINE button.

4) The current call will be put on hold.

5) Toggle between the calls using the LINE buttons.

#### **ENDING A CALL**

End a call by pressing the "EndCall" soft key or hang up the phone.

## CALL HOLD/RESUME

1) Hold: Place a call on "hold" by pressing the hold button.

2) Resume: Resume call by pressing the corresponding blinking LINE button.

**CALL TRANSFER** 

## Blind Transfer:

1) Press transfer button.

2) Dial the number and press the send button

\_\_\_\_\_ to complete transfer of active call.

#### Attended Transfer:

1) Press an idle line key to make a new call and the active LINE will be placed on hold automatically.

2) Once the call is established, press transfer 2-2

button followed by the LINE button of the held line to transfer the call.

3) After the call is transferred, phone will display idle screen.

## **3-WAY CONFERENCE**

#### Initiate a Conference Call:

1) Press conference button to bring up conference dialing screen.

2) Dial the third party number followed by SEND key.

3) When the call is established to the third party,

press the "ConfCall" soft key to initiate

3-way conference.

#### Cancel a Conference Call:

1) Press "Cancel" soft key on conference dialing screen to resume the two-way conversation.

## Hold The Conference:

1) Press hold button 🛄 to hold the

conference call with all parties are on hold;

2) Press "ReConf" soft key to resume conference call; or select the corresponding blinking LINE to speak with an individual party.

#### End The Conference:

The conference will be terminated for all three parties if the conference initiator hangs up or presses "EndCall" soft key.

## VOICEMAIL MESSAGE

1) A blinking red MWI (Message Waiting Indicator) indicates a message is waiting.

2) Press the Message button to retrieve the message. Prompts will walk the user through the process of message retrieval.

#### MUTE/DELETE

1) Press the MUTE button ( to mute/ unmute the microphone.

2) The Mute icon Not indicates whether the microphone is muted.

VOLUME ADJUSTMENTS

Use the volume button (- -----+) to

adjust the ring volume when the phone is idle.

Press the volume button during an active call to adjust the call volume.